




Flight Case Portable Z-Style

Product code: E804001/E804002

Incl. Trolley Wheels | Black/White

Preface

Thank you for purchasing this Showgear product.

The purpose of this user manual is to provide instructions for the correct and safe use of this product.

Keep the user manual for future reference as it is an integral part of the product. The user manual shall be stored at an easily accessible location.

This user manual contains information concerning:

- Safety instructions
- Intended and non-intended use of the device
- Installation and operation of the device
- Maintenance procedures
- Troubleshooting
- Transport, storage and disposal of the device

Non-observance of the instructions in this user manual may result in serious injuries and damage of property.

©2026 Showgear. All rights reserved.

No part of this document may be copied, published or otherwise reproduced without the prior written consent of Highlite International.

Design and product specifications are subject to change without prior notice.

For the latest version of this document or other language versions, please visit our website www.highlite.com or contact us at service@highlite.com.

Highlite International and its authorized service providers are not liable for any injury, damage, direct or indirect loss, consequential or economic loss or any other loss arising from the use of, or inability to use or reliance on the information contained in this document.

Highlite International B.V. – Vestastraat 2 – 6468 EX Kerkrade – the Netherlands

Table of contents

1. Introduction.....	3
1.1. Before Using the Product.....	3
1.2. Intended Use.....	3
1.3. Product Lifespan.....	3
1.4. Text Conventions.....	3
1.5. Symbols and Signal Words.....	4
2. Safety.....	5
2.1. Warnings and Safety Instructions.....	5
2.2. Requirements for the User.....	5
3. Description of the Device.....	6
3.1. Front View.....	6
3.2. Back View.....	6
3.3. Product Specifications.....	7
3.4. Dimensions.....	8
4. Installation.....	9
4.1. Installation Site Requirements.....	9
4.2. Safety Instructions for Installation.....	9
4.3. Assembly.....	9
5. Maintenance.....	12
5.1. Preventive Maintenance.....	12
5.1.1. Basic Cleaning Instructions.....	12
5.2. Corrective Maintenance.....	12
6. Deinstallation, Transportation and Storage.....	13
7. Disposal.....	13

1. Introduction

1.1. Before Using the Product

**Important**

Read and follow the instructions in this user manual before installing, operating or servicing this product.


The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual.

After unpacking, check the contents of the box. If any parts are missing or damaged, contact your Highlite International dealer.

Your shipment includes:

- Table top
- Bottom, including utility shelf
- 2 x Z-panels
- User manual

Figure 1



1.2. Intended Use

This device is intended for professional use as a foldable table in the entertainment industry.

Any other use, not mentioned under intended use, is regarded as non-intended and incorrect use.

1.3. Product Lifespan

This device is not designed for permanent operation.

1.4. Text Conventions

Throughout the user manual the following text conventions are used:

- References: References to parts of the device are in bold lettering, for example: "turn the **adjustment handle (05)**". References to chapters are hyperlinked
- 0–255: Defines a range of values
- Notes: **Note:** (in bold lettering) is followed by useful information or tips

1.5. Symbols and Signal Words

Safety notes and warnings are indicated throughout the user manual by safety signs.

Always follow the instructions provided in this user manual.

**DANGER**

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

**WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

**CAUTION**

Indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury.

**Attention**

Indicates important information for the correct operation and use of the product.

**Important**

Read and observe the instructions in this document.

2. Safety

**Important**

Read and follow the instructions in this user manual before installing, operating or servicing this product.

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual.

2.1. Warnings and Safety Instructions

**DANGER**

Danger for children

For adult use only. The device must be installed beyond the reach of children.

- Do not leave any parts of the packaging (plastic bags, polystyrene foam, nails, etc.) within the reach of children. Packaging material is a potential source of danger for children.

**Attention**

Before each use, examine the device visually for any defects.

Make sure that:

- All screws used for installing the device or parts of the device are tightly fastened and are not corroded.
- There are no deformations on housings, fixings and installation points.

**Attention**

For professional use only

This device must be used only for the purposes it is designed for.

This device is designed to be used as a foldable table. Any incorrect use may lead to hazardous situations and result in injuries and material damage.

- This device is not suitable for households.
- This device does not contain user-serviceable parts. Unauthorized modifications to the device will render the warranty void. Such modifications may result in injuries and material damage.

2.2. Requirements for the User

This product may be used by ordinary persons. Maintenance may be carried out by ordinary persons. Installation and service shall be carried out only by instructed or skilled persons. Contact your Highlite International dealer for more information.

Instructed persons have been instructed and trained by a skilled person, or are supervised by a skilled person, for specific tasks and work activities associated with the installation, service and maintenance of this product, so that they can identify risks and take precautions to avoid them.

Skilled persons have training or experience, which enables them to recognize risks and avoid hazards associated with the installation, service and maintenance of this product.

Ordinary persons are all persons other than instructed persons and skilled persons. Ordinary persons include not only users of the product but also any other persons that may have access to the device or who may be in the vicinity of the device.


3. Description of the Device

The Showgear Flight Case Portable Z-Style is a versatile, foldable solution that seamlessly converts into a sturdy flight case. The Portable Z-Style Table is ideal as a DJ table, but is also very handy as a table for audio and lighting consoles, and can even be used at trade shows and exhibitions. The table's unique Z-style configuration allows one half of the flight case to serve as a spacious tabletop, while the other half reinforces the legs and features a utility shelf for extra gear and storage. The tabletop includes two cable holes for easy cable management, ensuring a clean and organised workspace.

The sides of the table are hinged, folding neatly into the tabletop. Internal hook-and-loop straps keep the shelf and sides firmly in place during transport, minimising movement and preventing damage. When set up, butterfly locks ensure the table remains stable and secure. For effortless mobility, the Showgear Portable Z-Style Table is equipped with two integrated wheels and double handles on each end, making it easy to transport and set up wherever you go.

3.1. Front View


Figure 2



- 01) Table top
- 02) 4 x cable guide
- 03) 8 x butterfly latch
- 04) 4 x carrying handle
- 05) 4 x protective cap
- 06) Utility shelf
- 07) 2 x hook

3.2. Back View

Figure 3



- 08) 2 x integrated wheel
- 09) Case bottom
- 10) 2 x rubber feet
- 11) 2 x Z-panel

3.3. Product Specifications

Model:	Flight Case Portable Z-Style
--------	------------------------------


Mechanical Specifications:

Height	280 mm
Width	1200 mm
Depth	600 mm
Main desk height	950 mm
Second desk height	300 mm
Weight	34,5 kg
Material	Wood
Material thickness	9 mm
Color	Black

Product Properties:

Flight case application	DJ case
Handles	Left side / right side
Handle type	Recessed
Tour label space	No
Castors	2
Castor size	75 mm
Castor type	Fixed without brake
Latch type	Butterfly
Hinge type	Fixed
Rubber feet	Yes

3.4. Dimensions

Figure 4

4. Installation

4.1. Installation Site Requirements

The device can be used only indoors.

4.2. Safety Instructions for Installation

**WARNING**

Incorrect installation can cause serious injuries and damage of property.


4.3. Assembly

**Attention**

Install the Flight Case Portable Z-Style with 2 persons.


To assemble the Flight Case Portable Z-Style, follow the steps below:

Figure 5




01) Open the **butterfly latches (03)** and place the **table top (01)** on the side.

Figure 6




- 02) Open the hook-and-loop straps that hold the **Z-panels (11)**.
03) Fold both **Z-panels (11)** up and close the 4 **butterfly latches (03)** on the **table top (01)**.

Figure 7




- 04) Lay the Flight Case Portable Z-Style on its side, as shown below.

Figure 8




05) Place the **case bottom (09)** on the **Z-panels (11)** and close the 4 **butterfly latches (03)** on the **Z-panels (11)**.

Figure 9



06) Place the Flight Case Portable Z-Style upright.
07) Fold the **utility shelf (06)** down and secure it in both **hooks (07)**.

Figure 10



5. Maintenance

5.1. Preventive Maintenance

**Attention**

Before each use, examine the device visually for any defects.

Make sure that there are no deformations on housings, fixings and installation points.

5.1.1. Basic Cleaning Instructions

Clean the device with a soft, lint-free cloth.

**Attention**

- Do not immerse the device in liquid.
- Do not use alcohol or solvents.

5.2. Corrective Maintenance

The device does not contain user-serviceable parts. Do not open the device and do not modify the device.

Refer repairs and servicing to instructed or skilled persons. Contact your Highlite International dealer for more information.

6. Deinstallation, Transportation and Storage

- Use the original packaging to transport the device, if possible.
- Clean the device before storing (see [5.1.1. Basic Cleaning Instructions](#) on page 12).
- Store the device in the original packaging, if possible.

7. Disposal

After the device is removed from service it can be disposed of as scrap.

